

USER'S MANUAL



Equipment group: Airbikes, stationary bicycles

Fitness Club 24 Sp. z o.o.
ul. Komorowicka 110, 43-300 Bielsko-Biała
+48 33 486 90 07 - sklep@fitnessclub24.pl

I. INSTALLATION

The equipment must be installed on a solid, flat and level surface.

It is recommended that the devices are used in a place that ensures free and safe use. The operation area for the bike should be approx. 8m².

II. BEFORE USE

Please note that while using this device, there may be threats to life and health. Observe the following instructions to avoid hazards:

- a) Children must not use sports equipment without the supervision of a guardian.
- b) The device should only be used for its intended purpose. Please read the operating instructions before using it.
- c) Check the device before using it. Damaged equipment should not be used.
- d) The device should not be used as a substitute for other physical exercises.
- e) During training with the device, always use the help of an observer who will ensure your safety against injury.
- f) Do not exceed the maximum allowable load weight indicated for the device.
- g) Do not exceed the maximum allowable user weight.
- h) During use, the loads must be secured against falling by means of securing elements designed for this purpose – if required for this device.
- i) In the event of a threat to life or health when using the device, immediately refrain from further use and report this fact to the service.
- j) Keep body parts, hair, loose clothing, etc., away from the moving parts of the bicycle.
- k) If the device is equipped with emergency safety measures, use them during training.
- l) If you are changing the position of the adjustable elements, before you start exercising, make sure that the adjustment lock is operational and that it is firmly seated in the opening.

III. OPERATION

- a) Do not exceed the maximum allowable user weight.
- b) Before starting the training, the adjustment elements should be properly set in order to ensure the proper ergonomics of the training. If you are adjusting the position of the adjustable elements, before you start exercising, make sure that the adjustment lock is operational and that it is firmly seated in the opening – if required for this device.
- c) Sit down in a way that enables you to perform the training correctly and safely.

IV. MAINTENANCE

- a) Do not use equipment that is damaged or has damaged or worn components.
- b) Do not remove labels and markings applied by the seller.
- c) Preventive maintenance plays a key role in the trouble-free operation of the equipment and minimizes the user's liability for possible faults. Check the condition of the equipment regularly.
- d) Ensure that anyone who carries out any adjustment, maintenance or repair work is properly qualified.

V. DEVICE CHECKLIST

Description Frequency	Frequency
Cleaning the upholstery **	Every day
Cleaning the handles **	Every day
Leveling	Every day
Brake inspection	Once a week
Checking screw connections	Once a week
Cleaning the frame	Once a week
Frame inspection	Once a month
Chain lubrication ***	As required
Lubrication of the rails, seatposts and handlebars	As required

Failure to perform the checks leads to the loss of the warranty.

* If applicable

** For cleaning, use agents that are safe for the materials, for example water with a mild detergent.

*** For lubrication, use the lubricants recommended by the seller. The use of other substances may void the warranty.

VI. FAILURES AND TROUBLESHOOTING

The table below includes the most common failures and ways to fix them. If you still have problems, please contact your dealer.

Failure	Solution
Ekran nie włącza się	✓ Check the correct position of the batteries: +, -. ✓ Check that the correct batteries are installed: AA 1,5 V. ✓ Check the connection of the power cables and their technical condition. ✓ Check for possible damage to the panel: cracked screen or other.
The saddle is not stable.	✓ Check that the adjustment knob is in the correct place. ✓ Tighten the knob.
The pedals are not stable.	✓ Check that the pedals are securely installed, as marked. ✓ Tighten the pedals.
Speed is not displayed on the screen.	✓ Check the connection to the computer and the technical condition of the cables. ✓ Check the motion sensor, its connection to the magnet.

VII. ADDITIONAL REMARKS

The equipment may be used only under the supervision of the owner or persons designated by them. The owner is responsible for indicating the persons authorized to supervise, control and use the device.

The device is intended for indoor commercial use.



Distribution & Service